

GETCSW(a)

GETCSW(a)

NAME

getcsw — get console switch register setting

SYNOPSIS

(getcsw = 46.)
getcsw ()

DESCRIPTION

Getcsw returns the console switch register setting.

SEE ALSO

DIAGNOSTICS